



1028 in 1

Brand Code Table

Brand	Model Code	Brand	Model
ALPIN	0252,0253,0764,0765	HUAMEI	0402,0460-0465,0
AUCMA	0288-0296,0462,0801,0974	HUALING	0317-0325,0452,0
AUX	0297-0300,0451,0474,0475,0809,0963	HUIFENG	0370,0882
BANSHEN	0264,0776	HUIKANG	0368,0441-0443,0
BOERKA	0383,0434,0436,0437,0895	HYUNDAI	0202,0433,0480,0
CARRIER	0203-0209,0235,0456-0458,0482-0486, 0563-0565,0590	JDC	0373,0440,0952
		JIANGNAN	0432,0944
CHANGHONG	0301-0308,0813,0817,0819	JINDA	0414,0926
CHIGO	0379-0382,0489,0515,0892	JINSONG	0389-0391,0446-0
CHOFU	0184-0187,0699	JOHSON	0245,0492,0757
CHUNLAN	0345-0350,0450,0453,0545-0546,0962	KANGLI	0374,0375,0887
CORONA	0155-0163,0459,0670	KELON	0282-0287,0473,0
CONROWA	0377,0889	KLIMATAIR	0225,0226,0452,0
CONSUL	0463,0975	KOLIN	0416-0418,0929
DAEWOO	0203-0209,0406,0717,0918	KONKA	0397,0457-0459,0
DAIKIN	0171-0183,0566,0574,0577,0683,0695	LG	0197-0200,0514,
DOCTOR	0221,0449,0733,0961	LIANGYU	0233,0451,0963
DONGBAO	0355-0361,0867,0870	LITTLE DUCK	0015-0020,0527
DONGXINBAO	0413,0925	LOREN-SEBO	0255,0471,0472,0
Electrolux	0216-0220,0569,0729,0732	MACQUAY	0234-0237,0465,04
FEDDERS	0498,0499,0500,0528	MICOM	0415,0927
FRESTECH	0277,0495-0497,0519,0520,0789	MIDEA	0260-0265,0526,0
FUJITSU	0127-0137,0464,0552-0554,0641,0976	MITSUBISHI	0001-0045,0476-0
FUNAI	0430,0481,0942,0993	MITSUBISHI	0568,0582,1028
GALANZ	0371,0372,0521,0883	NORITZ	0431,0943
GUQIAO	0244,0291,0803	PANASONIC	0138-0154,0483,0
GLEE	0398,0399,0900	National	0995
GOLDSTAR	0201,0466-0469,0713,0980	PANDA	0378,0890
GREE	0309-0316,0482,0512,0513	PHILCO	0210,0211,0487,0
HAIER	0266-0272,0453-0455,0538,0539,0966	PROTON	0421-0423,0934
HISENSE	0332-0335,0505-0506,0517,0844	RAYBO	0362-0367,0876
HITACHI	0118-0126,0630,0637	ROWA	0369,0438,0439,04
HUABAO	0336-0344,0850	Sabro	0435,0506-0508,1
HUAKE	0408,0920	SAIJO DENKI	0212-0215,0724

Brand	Model Code		
HUAMEI	0402,0460-0465,0972		
HUALING	0317-0325,0452,0831		
HUIFENG	0370,0882		
HUIKANG	0368,0441-0443,0953		
HYUNDAI	0202,0433,0480,0714		
JDC	0373,0440,0952		
JIANGNAN	0432,0944		
JINDA	0414,0926		
JINSONG	0389-0391,0446-0448,0959		
JOHSON	0245,0492,0757		
KANGLI	0374,0375,0887		
KELON	0282-0287,0473,0485-0488		
KLIMATAIR	0225,0226,0452,0738		
KOLIN	0416-0418,0929		
KONKA	0397,0457-0459,0909		
LG	0197-0200,0514,1026		
LIANGYU	0233,0451,0963		
LITTLE DUCK	0015-0020,0527		
LOREN-SEBO	0255,0471,0472,0983		
MACQUAY	0234-0237,0465,0468,0472,0587,0977		
MICOM	0415,0927		
MIDEA	0260-0265,0526,0772,0776		
MITSUBISHI	0001-0045,0476-0479,0522,0523, 0568,0582,1028		
NORITZ	0431,0943		
PANASONIC	0138-0154,0483,0490-0492,0651,		
National	0995		
PANDA	0378,0890		
PHILCO	0210,0211,0487,0488,1000		
PROTON	0421-0423,0934		
RAYBO	0362-0367,0876		
ROWA	0369,0438,0439,0494,0527,0531,0881		
Sabro	0435,0506-0508,1018		
SAIJO DENKI	0212-0215,0724		
	·		

Brand	Model Code		
SAMPO	0424-0426,0938		
SAMSUNG	0188-0196,0516,0518,0700,0707		
SANYO	0046-0095,0558,0529,0530,0606		
SASUKI	0254,0470,0982		
SHANGLING	0384-0388,0444,0445,0956		
SHANXING	0392,0449,0961		
SHARP	0096-0106,0525,0542,0608,0616		
SHENGFENG	0376,0480,0992		
SHINCO	0351-0354,0454-0456,0866		
SHUANGLU	0376,0404-0407,0480,0992		
SHUAIKANG	0288,0800		
SONGGE	0428,0429,0941		
SOVA	0409,0410,0921		
SUMMER	0427,0939		
SUNDURG	0257,0505,1017		
SWAN	0434,0477,0516,0524,0946		
TADIRAN	0246-0251,0758,0762		
TATUNG	0419,0420,0932		
TCL	0273-0281,0476,0493,0570,0786,0793		
TECO	0256,0473-0475,0768,0987		
TIANDI	0415,0927		
TOSHIBA	0107-0117,0479,0561,0562,0489, 0629,1001		
TRANE	0227-0232,0739,0744		
UNI-AIR	0222-0224,0450,0735,0962		
WEILI	0393-0396,0908		
Whirlpool	0164-0170,0502,0681,1014		
WINIA	0481,0550,0993		
XILENG	0411,0412,0923		
XINLE	0400,0401,0913		
YANGZI (YAIR)	0403,0915		
YINYAN	0258,0259,0330-0331,0326-0331, 0478,0838		
YORK	0107,0238-0243,0501-0502,0573,0751		

MADE IN CHINA











- · Human motion detection
- Temperature and humidity display
- · Multi-angle signal emission
- · Motion light function

1028 in 1






Universal Air-conditioner Remote Control User's Guide

KT-PIR1 is a PIR human detection remote designed by our technical staff. It can detect the human motion within a certain distance and control the operation of air conditioner according to the human motion detected, which can save the energy. Through setting, it can be used as a night lamp. The LCD screen will light up when people are coming. After a period of time, it will turn off the backlight automatically. This remote can work as a thermometer, a hygrometer and also a clock. It also has timer on/off function. Supported by a bracket, it can stand on the table, which is of simplicity and fashion. The perfect design provides you with convenience, and it is definitely your best choice. Thank you for choosing our products. It is our biggest wish to provide convenience for your daily life. Please read this user's guide carefully before using it, which will help you to get the most from the remote control.

Display panel Description



PIR human detection setting

- 1. Press the "PIR" key, the LCD screen will display "Delay stop", and PIR Delay stop function starts. After starting the PIR mode, the air conditioner would turn off automatically where there is no human motion detected in half an hour.

 2. Press the "PIR" key again, the LCD screen will display "Eco", the PIR Eco function will start. In cooling mode, if no human motion is detected in 15 minutes, the setting temperature will raise 1°C. If no human motion is detected in 30 minutes, the setting temperature will raise 2°C. With human motion detected, the temperature would return to setting temperature. In heating mode, if no human motion is detected in 15 minutes, the setting temperature will decrease 1°C. If no human motion is detected in 30 minutes, the setting temperature will decrease 2°C. With human motion detected, the temperature would return to setting temperature.

 3. Press the "PIR" key again to exist the PIR mode.

Night lamp setting

- 1. Turn on the night lamp: press "Mode" key and "Enter" key simultaneously, you can see " 🔌 " displays on the LCD. The night lamp function is on

Drand Code Setting

1. Open the battery cover, put 3 AAA(UM-4,R03)batteries as per polar indicated on battery cabin.

2. Find the code from brand code list. If there are many codes for one brand, you have to try the first, if it doesn't work, please try the second until it works. For example: AUCMA, first you try "0288", if it doesn't work, try "0289".

3. Press "SELECT" key, brand code on LCD will flash, press " \(\text{w} \) " or " \(\text{w} \) " until required brand code appears. Then press "ENTER" key, the brand code stops flashing. Setting is complete, and you can control your air conditioner.

Auto-Search code setting

If you don't know brand of your air-conditioner or you can't find required brand from brand code list, please operate as per the following step:

1. Insert batteries, and make remote aim at air-conditioner. Press and hold "SELECT" key for 3 seconds, then release it. (The code displayed on the LCD screen increases automatically) When the air conditioner receives the corresponding signal and produces buzzer sound, press any key to confirm the setting quickly.

2. After turning on the air conditioner, try other function keys. If they do not work, repeat above steps until it is correct.

Clock setting

Timer on setting

Ilmer on setting
you can set timer on only after turning off your air conditioner.

1. Press the "TIMER" key, the clock signal " [No] "on LCD appears and time flashes.

2. Press " ▼ " " ▲ ", adjust to the time you want to turn on the air conditioner.

3. Time stops flashing after 10 seconds. The LCD displays current time and timer signal " [NO] ". Now setting is finished.

Timer off setting
you can set timer off only after turning on your air conditioner.

1. Press the "TIMER" key, the clock signal " ●FFO "on LCD appears and time flashes.

2. Press " ▼ " A adjust to the time you want to turn off the air conditioner.

3. Time stops flashing after 10 seconds. The LCD displays current time and timer signal ●FFO ". Then setting is finished.

Marks: 1) The time range that you can set is 00-24 hours.

2) Press "TIMER" twice in succession, the timer on/ off function is canceled.

3) Press "TIMER" key to check the time of timer on the LCD. After 5 seconds, it will return to display the current time.

4) After the timer setting finishes, ensure the remote aiming at the air conditioner and within effective distance.

Otherwise the setting is invalid.

Otherwise the setting is invalid.

- The valid distance of PIR human detection is about 8 meters, and the effective distance can be greatly influenced by the external factors. Such as: the temperature, detection angle and obstructions, etc. So you need to pay attention to these

- external factors. Such as: the temperature, detection angle and obstructions, etc. So you need to pay attention to tnese factors when using.

 If the remote is not used for a long time, remove the battery so as to avoid leakage liquid of the battery damaging the machine. When the LCD looks dim, please change batteries. (New and old batteries can not be used together).

 Susually, the LCD displays the current time. Press "ENTER" key to check the selected code on the LCD. After 5 seconds, it returns to display the current time.

 If the timer on/off doesn't work, please check carefully to see if there is obstacle between the remote and air conditioner. Because the operation is effective only when the air conditioner receives the timer on/off signal from remote controller.

 The manufacturer keeps the right to change the parameter and function of product.

Technical Parameters

Controllable distance: Larger than 8 meters The voltage: DC4.5V

Battery model: Battery AAA(UM-4, R03)*3
Dimension: L111.5mm*W74.4mm*D22mm(without the lens)
Weight: ApproX80g(without batteries)

Name: QUNDA Control Technology(Jiangsu)Co.,Ltd. Address: NO.888 LongQiao road, wujiang economy development area, suzhou, jiangsu, China

Post code: 215200 Web site: www.qunda.com

